



This document contains the parts list and weights for each size of Ohenry High Peak Pole Tent.

OHENRY HIGH PEAK KIT PARTS LISTS & WEIGHTS

20'x20' High Peak Pole tent!

20x20 High Peak Tent Top & hardware kit (no walls). Kit includes: 20x20 tent top, 8-side poles, 1-14' center pole, 12-30" stakes, and 12 Ratchet Handles. Shipping weight = 407 LBS (excluding sidewalls)

20'x30' High Peak Pole tent!

20'x30' High Peak Tent Top & hardware kit (no walls). Kit includes: tent top, 10-side poles, 2-14' center poles, 14-24" stakes, and 14 Ratchet Handles. Shipping weight = 499LBS (excluding sidewalls)

20'x40' High Peak Pole tent!

20x40 High Peak Tent Top & hardware kit (no walls). Kit includes: 20x40 High Peak Tent top, 12-side poles, 2-14' center pole, 16-30" stakes, and 16 Ratchet Handles. Shipping weight = 559 LBS (excluding sidewalls)

30'x30' High Peak Pole tent!

30'x30' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x30' High Peak tent top (2-sections), 16-side poles, 1-21' center poles, 20-42" stakes, 4-Ratchet Sets, and 16 Ratchet Handles. Shipping weight = 733 LBS (excluding sidewalls)

30'x50' High Peak Pole tent!

30'x50' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x50' High Peak tent top (3-sections), 20-side poles, 2-21' center pole, 24-42" stakes, 4-Ratchet Sets, and 20 Ratchet Handles. Shipping weight = 1007 LBS (excluding sidewalls)

30'x70' High Peak Pole tent!

30'x70' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x70' High Peak tent top (4-sections), 24-side poles, 3-21' center pole, 28-42" stakes, 6-Ratchet Sets, and 22 Ratchet Handles. Shipping weight = 1253 LBS (excluding sidewalls)

30'x90' High Peak Pole tent!

30'x90' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x90' High Peak tent top (5-sections), 28-side poles, 3-21' center pole, 32-42" stakes, 8-Ratchet Sets, and 24 Ratchet Handles. Shipping weight = 1499 BS (excluding sidewalls)

30x110' High Peak Pole tent!

30'x110' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x110' High Peak tent top (6-sections), 32-side poles, 5-21' center poles, 36-42" stakes, 10-Ratchet Sets, and 26 Ratchet Handles. Shipping weight = 1910LBS (excluding sidewalls)

30'x130' OHenry Pole Tent!

30'x130' High Peak tent Top & hardware kit (no walls). Kit includes: 30'x130' High Peak tent top (7-sections), 36-side poles, 6-21' center pole, 40-42" stakes, 12-Ratchet Sets, and 28 Ratchet Handles. Shipping weight = 2156 LBS (excluding sidewalls)

40'x40' High Peak Pole tent!

40'x40' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x40' High Peak tent top (2-sections), 16-side poles, 1-21' center pole, 20-42" stakes, 2-Ratchet Sets, and 18 Ratchet Handles. Shipping weight = 839 LBS (excluding sidewalls)

40'x60' High Peak Pole tent!

40'x60' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x60' High Peak tent top (3-sections), 20-side poles, 2-21' center pole, 24-42" stakes, 4-Ratchet Sets, and 20 Ratchet Handles. Shipping weight = 1104 LBS (excluding sidewalls).

40'x80' High Peak Pole tent!

40'x80' High Peak Tent Top & hardware kit (no walls). Kit includes: 40'x80' High Peak tent top (4-sections), 24-side poles, 3-21' center pole, 28-42" stakes, 6-Ratchet Sets, and 22 Ratchet Handles. Shipping weight = 1369 LBS (excluding sidewalls)

40'x100' High Peak Pole tent!

40'x100' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x100' High Peak tent top (5-sections), 28-side poles, 4-21' center pole, 32-42" stakes, 8-Ratchet Sets, and 24 Ratchet Handles. Shipping weight = 1634 LBS (excluding sidewalls).

40'x120' High Peak Pole tent!

40'x120' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x120' High Peak tent top (6-sections), 32-side poles, 5-21' center pole, 36-42" stakes, 10-Ratchet Sets, and 26 Ratchet Handles. Shipping weight = 2004 LBS (excluding sidewalls)

40'x140' High Peak Pole Tent!

40'x140' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x140' High Peak tent top (7-sections), 38-side poles, 6-21' center pole, 40-42" stakes, 12-Ratchet Sets, and 28 Ratchet Handles. Shipping weight = 2434 LBS (excluding sidewalls)

40'x160' High Peak Pole Tent!

40'x160' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x160' High Peak tent top (8-sections), 44-side poles, 7-21' center pole, 44-42" stakes, 14-Ratchet Sets, and 30 Ratchet Handles. Shipping weight = 2860 LBS (excluding sidewalls)

40'x180' High Peak Pole Tent!

40'x180' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x180' High Peak tent top (9-sections), 50-side poles, 8-21' center pole, 48-42" stakes, 16-Ratchet Sets, and 32 Ratchet Handles. Shipping weight = 3290 LBS (excluding sidewalls)

40'x200' High Peak Pole Tent!

40'x200' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x200' High Peak tent top (10-sections), 56-side poles, 9-21' center pole, 52-42" stakes, 18-Ratchet Sets, and 34 Ratchet Handles. Shipping weight = 3720 LBS (excluding sidewalls)

40'x220' High Peak Pole Tent!

40'x220' High Peak tent Top & hardware kit (no walls). Kit includes: 40'x220' High Peak tent top (11-sections), 62-side poles, 10-21' center pole, 56-42" stakes, 20-Ratchet Sets, and 36 Ratchet Handles. Shipping weight = 4150 LBS (excluding sidewalls)

60'x60' High Peak Pole tent!

60'x60' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x60' High Peak tent top (2-sections), 32-side poles, 2-21' center poles, 36-42" stakes, 2-Ratchet Sets, and 34 Ratchet Handles. Shipping weight = 1433 LBS (excluding sidewalls)

60'x80' High Peak Pole tent!

60'x80' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x80' High Peak tent top (3-sections), 36-side poles, 4-21' center poles, 40-42" stakes, 4-Ratchet Sets, and 36 Ratchet Handles. Shipping weight = 1891 LBS (excluding sidewalls)

60'x100' High Peak Pole tent!

60'x100' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x100' High Peak tent top (4-sections), 40-side poles, 6-21' center poles, 44-42" stakes, 6-Ratchet Sets, and 38 Ratchet Handles. Shipping weight = 2244 LBS (excluding sidewalls)

60'x120' High Peak Pole tent!

60'x120' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x120' High Peak tent top (5-sections), 44-side poles, 8-21' center poles, 48-42" stakes, 8-Ratchet Sets, and 40 Ratchet Handles. Shipping weight = 2597 LBS (excluding sidewalls)

60'x140' High Peak Pole tent!

60'x140' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x150' High Peak tent top (6-sections), 48-side poles, 10-21' center poles, 52-42" stakes, 10-Ratchet Sets, and 42 Ratchet Handles. Shipping weight = 3010 LBS (excluding sidewalls)

60'x160' High Peak Pole tent!

60'x160' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x160' High Peak tent top (8-sections), 52-side poles, 12-21' center poles, 56-42" stakes, 12-Ratchet Sets, and 44 Ratchet Handles. Shipping weight = 3363 LBS (excluding sidewalls)

60'x180' High Peak Pole tent!

60'x180' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x180' High Peak tent top (9-sections), 56-side poles, 14-21' center poles, 60-42" stakes, 14-Ratchet Sets, and 46 Ratchet Handles. Shipping weight = 3881 LBS (excluding sidewalls)

60'x200' High Peak Pole Tent!

60'x200' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x200' High Peak tent top (10-sections), 60-side poles, 16-21' center poles, 64-42" stakes, 16-Ratchet Sets, and 48 Ratchet Handles. Shipping weight = 4399 LBS (excluding sidewalls)

60'x220' High Peak Pole Tent!

60'x220' High Peak Tent Top & hardware kit (no walls). Kit includes: 60'x220' High Peak tent top (11-sections), 64-side poles, 18-21' center poles, 68-42" stakes, 18-Ratchet Sets, and 50 Ratchet Handles. Shipping weight = 4917 LBS (excluding sidewalls)